


LEGO DIGITAL DESIGNER 4.2

Model Name:
LegoLish_FilterSlider

Number of Bricks: 23



Step 1 of 6


2 x







1 x




1 x








Step 2 of 6

- 1 x 
- 1 x 
- 1 x 
- 1 x 



Step 3 of 6

- 1 x 
- 1 x 
- 1 x 
- 1 x 



Step 4 of 6


2 x



1 x



1 x




Step 5 of 6

2 x





1 x





Step 6 of 6


- 1 x 
- 1 x 
- 2 x 





2 x  611126 BRICK 1X10 - Black


1 x  611126 BRICK 1X12 - Black


6 x  265326 SLIDING PIECE 1X4 - Black

2 x  370226 TECHNIC BRICK 1X8 - Black

2 x  371026 PLATE 1X4 - Black

3 x  379526 PLATE 2X6 - Black

3 x  383226 PLATE 2X10 - Black

4 x  6001494 PLATE 2X14 - Black

© 2012 The LEGO Group. All rights reserved.
Use of the LEGO Digital Designer html print tool, signifies your agreement to the terms of use.